



AuthorityViewer



AUTHORITYVIEWER

Contents	
Disclaimer.....	3
Terms Used	4
General.....	5
How To	6
Get Started.....	6
Navigate to AuthorityViewer	6
Inside AuthorityViewer	7
The Map	7
Tools.....	7
Layers	8
Names and Progression	8
View	8
Details	9
Authority History.....	10
Upload a File	10
Step 1	10
Step 2	11
Step 3	11
Conclusion.....	12

Disclaimer

This document contains proprietary and confidential information.

All data submitted to the recipient is provided in reliance upon its consent not to use or disclose any information contained herein except in the context of its business dealings with PelicanCorp and MISS DIG 811.

The recipient of this document agrees to inform its present and future employees, employers, and partners who view or have access to the document's content of its confidential nature.

The recipient agrees to instruct each employee that they must not disclose any information concerning this document to others except to the extent that such matters are generally known to, and are available for use by, the public.

The recipient also agrees to not duplicate or distribute or permit others to duplicate or distribute any material contained herein without PelicanCorp's express written consent.

PelicanCorp retains all title, ownership and intellectual property rights to the material and trademarks contained herein, including all supporting documentation, files, marketing material, and multimedia.

Nothing in this proposal constitutes a license for recipient to utilize PelicanCorp's/MISS DIG 811's technology or intellectual property rights.

BY ACCEPTANCE OF THIS DOCUMENT, THE RECIPIENT AGREES TO BE BOUND BY THE AFOREMENTIONED STATEMENT.





AUTHORITYVIEWER


Terms Used

Term	Definition
<i>Area of Interest (AOI)</i>	Represents the location(s) of a facility owner/operator's underground facilities and is a layer contained within each station.
<i>AuthorityViewer</i>	Web-based program within DamagePreventionPortal that allows authorized users to view and update an AOI. Updates are completed by replacement file uploads only; no drawing tools.
<i>DamagePreventionPortal (DPP)</i>	The platform used by members to access and manage their membership; also used by the MISS DIG 811 Member Services Department.
<i>KML/KMZ File</i>	Stands for "Keyhole Markup Language," which is an XML notation for expressing geographic annotation and visualization within 2D maps and 3D Earth browsers. A KMZ file is a zip-compressed KML file. Either file type can be used as an AOI layer.
<i>Layer</i>	A layer contains features (polygons) that represent the AOI of a station.
<i>Member Service Support Form</i>	Online form used internally by department to collect varying information from members.
<i>OneCallAccess (OCA)</i>	Ticket entry platform used to place dig and design tickets; used internally by Notification Center NSRs or by external users. Excavators can use to search tickets placed and check Positive Response.
<i>Pelican/PelicanCorp</i>	PelicanCorp is the creator of the DamagePreventionPortal and OneCallAccess; they are typically referred to as our "vendor."
<i>SHP File</i>	The shapefile format is a geospatial vector data format for geographic information system software; can be uploaded into AuthorityViewer.
<i>Station</i>	Essentially an asset on the DamagePreventionPortal under a membership; stations are most often per separate facility type but some members use stations to break up a single-facility-type-asset into regions; only one facility type can be applied to a station; contains ticket notification settings, Summary Report settings, contact information, and area of interest. Each station is assigned a unique identifier called a "station code."
<i>Station Code</i>	A unique identifier assigned to each station that should follow standard naming procedure to summarize company name and facility type.
<i>Subscription</i>	One of the many possible deliveries to a member based on ticket criteria and destination; applied to station(s); can be email, IVR, or webhook.
<i>Ticket</i>	A communication from MISS DIG 811 to a facility owner/operator or their third party requesting the marking of underground facilities, based on information provided by an excavator in a dig notice.
<i>Transmission</i>	A transmission is a delivery of a single ticket and revision number through a single subscription; triggered by the shapes in the AOI.
<i>User Account</i>	Account associated with each membership that allows authorized users to access and manage membership through the DamagePreventionPortal; starts in OneCallAccess.
<i>Work Polygon</i>	The polygon drawn by a MISS DIG 811 NSR or external use on each ticket placed depicting the work/dig location; the work polygon is intended as virtual white lining.

General

AuthorityViewer is the program within DamagePreventionPortal that allows users to view the area of interest (AOI) and upload replacement files per individual station associated with their user account. This AOI is what triggers transmission (a.k.a. “delivery”) of tickets when it intersects with the work polygon drawn on tickets.

AuthorityViewer is entirely web-based and does not require download and installation. This program does not contain drawing tools; all shapes must be created outside of AuthorityViewer in other programs such as GIS software or Google Maps. Refer to the *PelicanCorp GIS Standards 2022* document at resources.missdig811.org for specifications.




How To

Get Started

Log into your DamagePreventionPortal (DPP) account at dpp.missdig811.org. Enter username and password.

If you would like to remain logged in, check the box labeled “Keep me logged in.” *Please take your organization’s security measures into account.*

If you have forgotten your username or password, click on the appropriate links at the bottom of the login box. All confirmation or reset emails will be sent from OCARS_PRO@missdig.org.



User account types with access to AuthorityViewer are Member Full/+, Member Admin/+, AuthorityViewer, and Explore Your Data/+. However, only Member Full/+ and AuthorityViewer account types allow for read/write access.

Navigate to AuthorityViewer

Viewing and editing is done per station. All stations associated with your user account can be found under **Settings: OneCallAccess**. To view or edit the AOI, open the desired station.

Settings > OneCallAccess
SYSTEM OPERATOR KCORMIER, PELICANCORP INTERNAL Cormier Communications

Stations Subscriptions Lookup Tables

Status State Search by station name or station code
Active All

Station code		State
CORCOMFBR	Cormier Communications Fiber	MI
CORCOMPH	Cormier Communications	MI
HORNCTV	Cormier Communications	MI
HORNPH	Cormier Communications Phone	MI

Within the station settings, you will click the white **Area of Interest** button to open AuthorityViewer.



On occasion, you may be prompted to log into AuthorityViewer. When this happens, your DPP user account credentials should be entered.

Inside AuthorityViewer

The Map


You can navigate the map to view shapes by inputting location information into the **Search** field. The information can be entered just as it would be when using Google Maps. You can also insert navigational Lat./Long. reference points in the **Reference Points** section.



Tools

You have access to the following tools:

- **Reset Position:** Resets map to the default view.
- **Upload Data:** Begins the file upload process.
- **Rollback Live:** Reverts the AOI to the previously live layer.
- **Authority History:** Enables user to keep notes and view a recent timeline of activity.



Layers

Names and Progression

AuthorityViewer categorizes and displays files that have been uploaded as different “layers”. The layer type indicates the status or phase of an uploaded file.

1. **Candidate:** The most recently uploaded file that has not yet been approved for publication. This will show up in **red**.
2. **Approved:** The most recently uploaded file that has been approved and can be scheduled for publication. This will show up in **orange**.
3. **Planned:** The most recently uploaded file that has been scheduled for publication. This will show up in **blue**.
4. **Live:** The active file that determines ticket delivery. This will show up in **green**.
5. **Previous:** The direct previous file that is inactive. This will show up in **orange**.
6. **Archived:** All other previously active files that are inactive. Archived layers will show up in **black**.

View

Layers of the map can be viewed by clicking the **Layer** icon near the top-right corner. Visible layers include map views and uploaded files from enabled user accounts.



Different map layers (a.k.a. “views”) that a user can experience.

All existing layers associated with the station code; users can turn viewing on/off for different layers by clicking the blue checkbox.

Users can download a copy of each layer by clicking the grey box showing the AOI ID.

Each layer is titled in the following format:

[AOI ID] [Layer Type] [Date/Time of Upload] [File Name]

The AOI ID is a unique identifier assigned to a layer by the Pelican system.

Details

The **Details** section provides details on the progression of layers from candidate to active so you can keep track of your work. When you upload a candidate layer, information on that layer will be populated here, including the Status (as “candidate”) and the Loaded Date. Once that candidate layer is approved, the Current Status will change to “Approved” and the Approved Date will become visible. This will continue through to a Live layer.

Details

Current Status : Candidate

Uploads : 12

Publishes : 9

Loaded date : 11/8/2021 9:30 AM (US Eastern Standard Time)

Approved date :

Published Date :



Details

Current Status : Approved

Uploads : 12

Publishes : 9

Loaded date : 11/8/2021 9:30 AM (US Eastern Standard Time)

Approved date : 11/8/2021 9:38 AM (US Eastern Standard Time)

Published Date :



Details

Current Status : Planned

Uploads : 12

Publishes : 9

Loaded date : 11/8/2021 9:30 AM (US Eastern Standard Time)

Approved date : 11/8/2021 9:38 AM (US Eastern Standard Time)

Published Date : 11/8/2021 9:50 AM (US Eastern Standard Time)



Details

Current Status : Live

Uploads : 13

Publishes : 10

Loaded date : 11/8/2021 9:30 AM (US Eastern Standard Time)

Approved date : 11/8/2021 9:38 AM (US Eastern Standard Time)

Published Date : 11/8/2021 9:50 AM (US Eastern Standard Time)

Authority History

Authority History allows you to keep notes and view the timeline of [recent] activity.



When the **Show Details** box is checked, you can view the timeline of recent activity within AuthorityViewer. Unchecking the box will allow you to see all comments added.

To add additional comments, click the **Add Comment** button.

Upload a File

Step 1

To upload a file, click the **Upload Data** icon.

File Types and Contents

When uploading a SHP (shape) file type, you must attach a compressed folder containing the following file types: SHP, SHX, PRJ, and DBF.

You can also import TAB files and KML/KMZ files in compressed folders, respectively.

Imported files can contain polygons, lines, or points.

The system imposes a minimum 1-foot buffer on line and point data; however, MISS DIG 811 recommends the use of a minimum 100-foot buffer. If you choose a buffer size below the recommended amount, please consider that ticket delivery is triggered by the intersection of the work polygon drawn by the excavator or MISS DIG 811 NSR, which now uses buffer size of only 75 feet to determine which members should receive the ticket. This 75-foot buffer is not seen by the excavator or facility owner/operator member.

At the present time, files imported only replace the active AOI. The system does not allow for additions to existing layers.

If you don't have the ability to create a replacement file, please use the [Member Service Support form](#) located on the [Member Utilities](#) page of MISS DIG 811 website at missdig811.org to submit the file(s). We are happy to assist you in combining files.

Step 2

Once the file is uploaded, it becomes a "candidate layer" that requires approval.

You must approve the candidate layer before it can be published on the server. Approving the candidate layer automatically turns the file into an "approved layer".

AOI Layer Approval

Approved :

Not Approved :

Archived :

Set Status

If you see an issue with the candidate layer, select "Not Approved" to stop the layer from becoming published.

After a selection has been made, you must click the green **Apply** button to process.

Step 3

You must now publish the approved layer.

You can set the publication date/time. The earliest a file can be published is 15 minutes out from the time the file was uploaded. Once a date/time has been selected, you must click **Done**.

You must then click the green **Publish** button if the date/time shown in the **Publish Date and Time** field is correct.

Publish Date

Publish Date and Time
(Your choice will show in your local timezone)

The time

September 2021

Su	Mo	Tu	We	Th	Fr	Sa
			1	2	3	4
5	6	7	8	9	10	11
12	13	14	15	16	17	18
19	20	21	22	23	24	25
26	27	28	29	30		

Time 00 : 00

Current Status :
Uploads :
Publishes :
Loaded date :
Approved date :
Published Date : +15 min

minutes. publish.

The soonest that you can publish is now + 15 minutes.
The time is converted to the service timezone when you publish.

Reference points

Setting a publication date/time automatically turns the approved layer into a blue “planned layer”. The file will remain a planned layer until the set publication date/time, when the file uploaded becomes active and will impact receipt of tickets.

Notes

- Verify the publication was successfully set to “planned” before exiting the window. If the publication does not take, there is no need to re-upload. You will need to complete the publication step again.
- Attempting to upload a second layer prior to the previous layer being published will cause issue with the creation of a live layer and will block future upload attempts.

Conclusion

This completes the AuthorityViewer instructional guide.

As a reminder, detailed guides on additional aspects of DamagePreventionPortal can be found at resources.missdig811.org.

Contact the Member Services Department through the online [Member Service Support form](#), by email at membersupport@missdig811.org, or (800) 482-7161 with questions regarding DamagePreventionPortal and membership.

Member Service Support

This form allows members to:

- Activate Excavator PosR API/Webhook Subscriptions
- Add OCA accounts to DPP
- Request updates to contact information
- Request updates to ticket delivery subscriptions
- Submit AOI files for upload
- Request information on becoming a member

Contact the Member Services Department for invoice inquiries, questions, and troubleshooting

Select one of the following *